



Adjustable Gauge Light Driver

Notes:

- Mount Q2 on a suitable heatsink using an insulated mounting kit,